Betty ^{TK1} by Thau & Kallio 2019







Product Fact Sheet



Betty ^{TK1} by Thau & Kallio 2019



Environment Indoor

Material

Lacquered or Oiled solid wood and formpressed veneer with natural linen and PP (Polypropylene) webbing. This product has not been treated with any biocides.

Production process

The chair is made from solid wood and formpressed veneer with a linnen webbing seat.

Gliders Felt gliders installed as standard.

Stacking quantity 8 pcs

Dimensions

H: 77cm/30.3in, W: 51cm/20.1in, D: 48cm/18.9in, Seating D: 42cm/16.5in, Seat H: 47cm/18.5in.

Packaging dimensions

H: 86cm/33.9in, W: 53.2cm/20.9in, D: 51.7cm/20.4in.

Colli quantity 1 (2 pcs)

Weight Product: 4 kg. Incl. packaging: 17.5 kg

Country of origin Latvia

Certifications



Strength, durability and safety testing The chair is tested for strength, durability and safety according to EN 16139 level 2 -Extreme use.

Cleaning instructions Please download our Material Care & Cleaning

instructions through <u>www.andtradition.com</u>

→ Stock items Black Oak Smoked Oak





→ Black Lacquered ash w. Black webbing → Black Lacquered ash w. Natural webbing



→ Oak Lacquered oak w. Natural webbing



→ Smoked Oiled oak w. Natural webbing

Related products



&Tradition®









Recycling & Disassembly

Betty TK1

RECYCLING

The Betty chair is built to last, and we hope that your Betty will serve you for many years. The chair is made from solid wood and wood veneer, and can be easily separated from its base. All metal and wooden parts can be separated and delivered to a suitable recycling station.

SPARE PARTS

To purchase spare parts for your Betty chair, please write to our sales support team at info@andtradition.com with your query.

5 YEAR WARRANTY

&Tradition provides a 5-year warranty with every Betty chair, which covers faults which were present at the time of purchase, or which have occurred as a result of a manufacturing defect. The warranty is valid from the date stated on the original invoice.



DISASSEMBLY

1. To disassemble the Betty chair first remove the webbing from the seat.



2. Unscrew the bolts located inside the frame of the seat. This can be done with a socket wrench.

3. Remove the gliders.



&Tradition[®]